

Device Alarms

Device Alarms are alarms that are triggered by door controllers, receivers, elevator controllers, or digital Input/Output devices (I/Os) under certain conditions. Device alarms show on your floorplan and point to the device that triggered the alarm.

Revision #1

Created 16 February 2022 16:40:14 by Admin

Updated 16 February 2022 16:40:42 by Admin