


How To: Change your Password

To access your user profile, click on your email address or
On this page you can change your password.



The screenshot displays the MyChild user interface. At the top left is the MyChild logo, featuring a bird icon and the text 'MyChild'. Below the logo is a navigation menu with the following items: Home, Patients, Tags, Floorplans (with a dropdown arrow), Reports (with a dropdown arrow), Admin (with a dropdown arrow), and Help (with a dropdown arrow). The main content area is divided into two panels. The left panel, titled 'Personal Details', contains the following fields: 'First Name:' with the value 'MyChild6', 'Last Name:' with the value 'Administrator', 'Auto-Logout Delay:' with a dropdown menu set to '0 seconds', 'Permission Level:' with the value 'SuperAdmin', 'Role:' with the value 'Nurse - Admin', and 'Pin:' with the value '4578'. A 'Save Details' button is located at the bottom of this panel. The right panel, titled 'Alarm Notifications', contains three sections: 'Subscribe to System Alarm' with an unchecked checkbox and a 'Select System Alarms' button; 'Subscribe to Patient Alarm' with an unchecked checkbox and a 'Select Patient Alarms' button; and 'Subscribe to Device Alarm' with an unchecked checkbox and a 'Select Device Alarms' button. A 'Save Alarm Notification Set' button is located at the bottom of this panel. The footer of the page contains the copyright notice: © 2023 - McRoberts Technologies | b

If you do not know your password, click the reset password button on the login page.

Login

Work Email:

Password:

Log in

[Reset password](#)

Revision #3

Created 3 February 2022 05:02:31 by Admin

Updated 27 June 2023 18:51:32 by Anna Olt